

INSTALLATION INSTRUCTIONS

Gianna Body Spray
Part #: S067-

JACLO[®]
Confidence from start to finish.™



INSTALLATION

1. Nipple should protrude 3/8" - 7/16" from finished wall.
2. Wrap plumbers tape around nipple.
3. Using cloth strap wrench, affix body spray to nipple.

To learn more about JACLO's warranty, please visit [**jaclo.com**](http://jaclo.com)