INSTALLATION INSTRUCTIONS

PVC Tub Drain Half Kits with Brass Trims

Part #: 540-PVCHK-, 542-PVCHK-, 541-PVCHK-, 531-PVCHK-, 535-PVCHK-, 537-PVCHK-, 549-PVCHK-, 543-PVCHK





540-PVCHK



535-PVCHK



542-PVCHK



537-PVCHK



541-PVCHK



539-PVCHK



531-PVCHK



543-PVCHK

HALF KIT INSTALLATION

This drain is designed for the installer to use their 1 1/2" PVC tubes, cut to the desired length, and install on bath tubs.

It is assumed that this work is being done by qualified plumbers who will be using the appropriate sealants and tools.



